



MODEL 835

FLOW CURVES



REPAIR PARTS & KITS - MODEL 835, 835B

FIG.	DESCRIPTION	Q.	3/4"		1"		1-1/2"		2"	
			835B	835	835B	835	835B	835	835B	835
2	Retainer	2	500-151	500-151	500-151	500-151	100-892	100-892	100-892	100-892
3A	Spring — 1st Check Spring		630-102	780-491	630-102	780-491	630-110	780-492	630-110	780-492
3B	Spring — Not Shown — 2nd Check Spring		630-103	630-091	630-103	630-091	630-109	630-092	630-109	630-092
14	Gate Valve		780-131	780-131	780-106	780-106	789-108	789-108	780-109	780-109
15	Gate Valve — Tapped		780-132	780-132	780-133	780-133	780-120	780-120	780-121	780-121
17	Test Cock	4	780-114	780-114	780-114	780-114	780-166	780-166	780-166	780-166
21	Diaphragm Cover		780-608	780-420	780-608	780-420	780-606	780-287	780-606	780-287
25	Capscrew	4	700-018	700-018	700-018	700-018	—	—	—	—
25	Capscrew	8	—	—	—	—	700-117	700-088	700-117	700-088
28	Spring		780-424	780-424	780-424	780-424	780-291	780-291	780-291	780-291
36	Seat Ring		780-603	780-429	780-603	780-429	780-625	780-295	780-602	780-295
38	Screw		700-107	700-107	700-107	700-107	700-106	700-106	700-106	700-106

KITS	DESCRIPTION	3/4"		1"		1-1/2"		2"		
		835B	835	835B	835	835B	835	835B	835	
	Check Kit (4, 5, 6, 16)	905-026	905-026	905-026	905-026	905-027	905-027	905-027	905-027	
	Rubber Parts (6, 16)	2	—	780-503	—	780-503	902-392	780-504	902-392	780-504
	Relief Valve (Inc. 36, 51)		780-582	—	780-582	—	780-601	902-392	780-601	902-392
	Relief Valve Kit (26, 28, 30, 32, 33, 35, 36, 38, 51)		905-030	902-403	905-030	902-403	905-031	902-404	905-031	902-404
	Bonnet Kit w/Name Plate (8, 16, 54, 57)		905-013	902-409	905-014	902-408	905-015	902-410	905-016	902-407
	Relief Valve Rubber Parts (26, 32, 39, 51)		905-032	—	905-032	—	905-033	—	905-033	—
	Bonnet Kit (7, 6A, 16)		902-389	—	905-389	—	905-391	—	905-391	—



MODEL 835B

FLOW CURVES

