

Model 806YD Assemblies & Repair Kits

Description	Qty.	Size 2½"	Size 3"	Size 4"	Size 6"	Size 8"	Size 10"
Spring Assembly (3, 4.1, 5, 6, 7, 7.1, 7.2, 9, - 11, 15, and 50)		905-086	905-088	902-467	902-469	902-471	902-473
Rubber Parts (11, 14, and 50)	-	905-059	905-060	905-061	905-062	905-063	905-064
Seat Kit (2, 2.1, 2.2 and 12)	-	902-386YD	902-385YD	902-384YD	902-383YD	902-382YD	902-381YD
Lg. Mounting Kit (16, 17, 17.1; Both Ends)	-	905-036	905-037	905-038	905-039	905-040	905-041
Cover Assembly (4, 4.1, 14, Aircock (not shown))	-	902-497	902-498	902-499	902-500	902-501	902-502

Model 806YD Individual Parts

Fig No.	Description	Qty.	Size 3"	Size 4"	Size 6"	Size 8"	Size 10"
9	Spring	2	630-141	780-778	780-779	780-780	780-781
Gate Valves							
42	Resilient Seated OS&Y	1	780-893	780-895	780-897	780-899	780-901
By-Pass							
300	Meter	1	-	-	-	-	-
301	Nipple	1	571-181-54	571-181-54	571-118-54	571-118-54	571-118-54
302	Ball Valve	1	781-048	781-048	781-048	781-048	781-048
303	Ball Valve	1	781-083	781-053	781-053	781-053	781-053
303.1	Test Cock	1	781-074	781-074	781-074	781-074	781-074
304	Elbow	5	571-111-50	571-111-50	571-111-50	571-111-50	571-111-50
305	Nipple	1	571-182-51	571-182-51	571-182-50	571-181-59	571-182-50
305.1	Nipple	2	571-182-41	571-182-52	571-182-52	571-182-52	571-182-52
306	Nipple	1	571-181-55	571-118-55	571-181-55	571-181-55	571-181-55
307.1	Tailpiece	2	780-777	780-777	780-777	780-777	780-777
308	Coupling Nut	2	780-665	780-665	780-665	780-665	780-665
309	Meter Washer	2	780-944	780-944	780-944	780-944	780-944
311	Nipple	1	571-118-153	571-118-153	571-118-153	571-118-153	571-118-153
312	805Y Less Shut-Off	1	907-001	907-001	907-001	907-001	907-001
313	Coupling	1	571-201-50	571-201-50	571-201-50	571-201-50	571-201-50



Parts (Sizes 4" through 10" only)

FIG. NO.	DESCRIPTION	QTY.	SIZE 4"	SIZE 6"	SIZE 8"	SIZE 10"
9	Spring	2	780-778	780-779	780-780	780-781
Gate Valves						
42	Metal Seated OS&Y-Inlet	1	780-925	780-927	780-928	780-929
42	Resilient Seated OS&Y-Inlet	1	780-895	780-897	780-899	780-901
42A	Metal Seated OS&Y-Outlet	1	780-925	780-927	780-928	780-929
42A	Resilient Seated OS&Y-Outlet	1	780-894	780-896	780-898	780-900
61	Inlet By-Pass Sub Assembly	1	902-503	902-503	902-503	902-503
61	Center By-Pass Sub Assembly	1	902-504	902-603	902-604	902-605
61	Outlet By-Pass Sub Assembly	1	902-505	902-505	902-505	902-505
61B	Meter (Std.-Gal.)	1	780-666	780-666	780-666	780-666
	Mainline Spring Assembly	2	902-514	902-515	902-516	902-517

For all other parts, please refer to Models 805Y & 805YD. The above parts are not interchangeable with Model 805Y/805YD.